
## BELLAVISTA


## Installation Guide

Model: SF-F-TD-78-82 SF-F-TD-82-86 SF-F-TD-86-92\*

SF-F-TD-86-92\* SF-F-TD-92-102\* SF-F-TD-102-112\* SF-F-TD-112-122\* SF-F-TD-122-132\*

## (\* = S04 Rail needs to be cut to size ==== )





S01:DOOR GLASS PANEL WITH HANDLE HOLE (WHEELS ALREADY INSTALLED)
S02: MIDDLE DOOR GLASS PANEL (WHEELS ALREADY INSTALLED)
S03: FIXED PANEL
S04: ALUMINUM RAIL FOR TOP AND BOTTOM
S05: ALUMINUM PROFILE FOR FIXED PANEL
S06: ALUMINUM CHANEL FOR DOOR MAGNETIC SEAL
S07: WALL CHANEL
S08: ALUMINUM CONNECTING PART FOR S01 AND S02
S09: DOOR HANDLE
S10: FIXED PANEL BLOCK
S11:DOOR MAGNETIC SEAL FOR S06
S12: DOOR MAGNETIC SEAL FOR S01
S13: PLASTICE SEAL FOR BETWEEN GLASS
S14: PLASTICE SEAL FOR FIXED PANEL AND ALUMINUM
S15: SCREWS FOR FIXING S07 TO WALL
S16: SCREWS FOR FIXING TOP AND BOTTOM TO S05
S17: SCREWS FOR FIXED PANEL BLOCK
S18: CORNER CONNECTOR IF USING RETURN PANEL(FRONT AND RETURN)OTHERWISE BIN IT
S19: SCREWS FOR S08
S20: SCREW PLUG FOR WALL CHANEL
S21:PLASTIC SCREW CAP
S22: SCREWS FOR LOCK S05 AND S07

